

Content of Hard Drive(199)

How do I convert DVD Karaoke disc into AVI files for DVD-105G USB, DVD-203G USB, DVD-305G USB, and JB-199 players?

Please refer the attached instruction for converting DVD Karaoke disc into AVI files for use in CAVS DVD-105G USB, 203G USB, 305G USB, aand JB-199 players.

Unique solution ID: #1175

Author: CAVS Support

Last update: 2010-04-25 10:01