

# Settings(199)

## How to chage the battery on the main board of JB-199

- Power off the Jb-199 unit completely and unplug the power cable.
- Take the top cover of JB-199 off by removing the 4 screws on each side and 3 screws on the back.
- On the mainboard, look for a (Quarter) coin size battery CS2032 and remove it by releasing the lock holding the battery. Do not damage the lock in the process.
- Insert a new CR2032 battery.
- Power on the JB-199 unit.
- Reset the BIOS setting of the mainboard following the instructions given in the following post.  
<http://cavsusa.com/kb/index.php?action=artikel&cat=10&id=166&artlang=en>

Unique solution ID: #1226

Author: n/a

Last update: 2021-05-25 14:56