

# Settings(99)

## How do I set a JB-99 Hard drive as a slave?

To do so please refer to the label on the hard drive as the setup is specific to that particular hard drive.

\*\*As reference please know that the label is referring to the pins between the power connector and the IDE cable. Please see attached image if you are still having trouble finding the pins.

Unique solution ID: #1082

Author: CAVS Support

Last update: 2009-04-16 03:36