

Functionality(199)

The front display on my JB-199 flashes.
Is there anything I can do to fix this?

Dear Customer:The flickering LCD may or may not blink out completely. To prepare for the work, please go to our website cavsusa.com > PRODUCTS > and to the webpage of your JB-199 player. Please take care to go to the correct page for your JB-199 (Type A or B, Regular or Premium, etc.). Then in the webpage, please upgrade your JB-199 player with the latest program using the full version. Also remove the existing version of JB-199 Manager program in your JB-199 player, and download and install the latest version of JB-199 Manager program from the same webpage. Having upgraded to the latest version of JB-199 program and JB-199 Manager program, your unit is now free of any trouble from the LCD status. LCD may or may not go out, but it will not interfere with your JB-199 operation. If you decide to replace the flickering LCD, you need to order a new front board for JB-199. The front board is same for all JB-199 player. Please email or call to our sales office for the replacement. Thanks.

Tech Support

CAVS USA

Unique solution ID: #1190
Author: CAVS Support
Last update: 2010-07-22 08:07