

Functionality(199)

What is the specific software in my JB-199?

JB-199 I
Serial: CUPMKC-*****

Upgradeable:

CPU Regular: Socket 478 Intel® Celeron® 4 processor.
CPU Premier: Socket 478 Intel® Pentium® 4 processor.

Note:
1. Must be Intel® Socket 478 CPU

Ram Regular: 256MB DDR-400 184 Pin
Ram Premier: 512MB DDR-400 184 Pin

Note:
1. Max capacity is 1 GB per slot(4 slots available)
2. Replace only with DDR-400 184 Pin RAM

[More info.](#)

JB-199 II
Serial: UMCCKC-*****

Upgradeable:

CPU Regular: Socket 775 Intel® Celeron® D processor.
CPU Premier: Socket 775 Intel® Pentium® Dual-Core processor.

Note:
1. Must be Intel® Socket 775 CPU

Ram Regular: 256MB DDR2 667/533 DIMM
Ram Premier: 512MB DDR2 667/533 DIMM

Note:
1. Max capacity is 2 GB per slot(2 slots available)
2. Replace only with DDR2 667/533 DIMM RAM

[More info.](#)

Unique solution ID: #1026

Author: JB-199 Tech

Last update: 2009-03-12 03:31