

Functionality(199)

when I record I do not have sound.

Make sure that you are connecting a cable from your mixer output into JB-199 audio in jacks on the back of the player. The player records the audio from this jacks.

Unique solution ID: #1046

Author: JB-199 Tech

Last update: 2009-03-18 06:08