

Settings(DVD)

How do I change my region code?

For 202G

- 1) Turn on the DVD-202G unit without a disc inside the tray. Open the tray.
- 2) Press the Setup button and bring the cursor down to Karaoke Setup.
- 3) Press 9999 followed by the regional code (ex. 1 for US, 6 for China, etc.). For all regions, press 9999 followed by 0 (zero).
- 4) Press the Setup button again and close the tray.

For 103G/105G/203G

- 1) Make sure that there is no disc in the tray.
- 2) Press Setup from the remote.
- 3) Press 9999 from the remote.
- 4) Press Stop from the remote.

Unique solution ID: #1010

Author: CAVS Support

Last update: 2009-03-12 03:19