

# Settings(DVD)

## **Is it possible to have your own splash background screen when you are selecting your track on the DVD-[model] player?**

Unfortunately, no. The splash screen is embedded directly onto the hardware of the player.

Unique solution ID: #1077

Author: CAVS Support

Last update: 2015-09-15 16:49