

# Touch Screen Karaoke Players

## How do I change the Hard Drive Power/Data Cable in my Shuttle Touchscreen PC

Please review the attachment for complete instruction on how to replace the Power/Data cable in your Shuttle All-in-One Touchscreen PC

Unique solution ID: #1287

Author: Chuck

Last update: 2016-03-24 16:45