

# 3D Customer Interface / Touch Screen

**Why did my 3D screen stop functioning? It opens and I can click on the different icon categories but nothing opens.**

Unique solution ID: #1340

Author: Le Voy Umphress

Last update: 2022-01-04 22:41