

USB/Hard drive(DVD)

Why does the unit scramble and reset itself after I push a certain song number?

This typically means that you have invalid characters in that particular song. (For instance, latin letters in Spanish songs). Here are the steps to resolve such an issue:

1. [How do I make sure my juke.txt file is properly formatted?](#)
2. [How can I create an INX menu, Address.inx and English.inx?](#)

*required for changes to your juke.txt file to take effect.

Note: If this problem occurs on SuperCDGs the issue is the same and you have to recreate the SuperCDG with a properly formatted juke.txt file using step 1 from above.

Unique solution ID: #1076

Author: CAVS Support

Last update: 2015-06-12 19:52