

USB/Hard drive(DVD)

What equipment do I need to insert CD+Gs to an external hard drive for CAVS DVD/USB Karaoke Players?

You will need the following to insert regular CD+G discs onto an external hard drive.

1. A Computer with:
 - ...a DVD-ROM drive.
 - ...our [MCG Manager](#) installed.
2. An External Hard drive.
 - *Certain specs must be met please view them before purchasing a hard drive.
 - *Specs: [What are the recommended hard drives for CAVS DVD/USB Karaoke Players?](#)
3. The CD+Gs you want to rip.

The tutorials are found within the program when you click "HELP" or temporarily here:

http://cavsusa.com/product/H_player/MCGManager.html

Unique solution ID: #1008

Author: CAVS Support

Last update: 2009-02-06 08:21